

Mixer should be stored in a cool, dry environment. Humid conditions can damage the motor windings, output bearings, and lubrication. The mixer shaft and impellers should be stored such that they are completely supported and no heavy items are stacked on them. Do not store the mixer near vibrating machinery. All of these factors may deteriorate your mixer.

For long storage periods, rotate the motor and drive assembly, and the mixer shaft once a month. If a gearbox is present, it should be stored in its actual mounting position in accordance with the specified oil level, in a clean and dry temperature-controlled area. If applicable, remove mechanical seal and carefully store in a safe place. Apply rust preventatives as desired. Be sure to change any lubricants before installation and recommissioning. Consult component manuals for Motor & Gearbox for long term storage.