

**BDRA SEAL IS SHOWN** 

1.) APPLY PROCESS COMPATIBLE

LUBRICANT TO THE O-RING ON THE

BOTTOM HALF OF THE SEAL AND THE O-RING IN THE TOP HALF OF THE SEAL. BEING CAREFUL NOT TO ALLOW ANY TO MAKE CONTACT WITH THE SEALS MATING SURFACES. BACK OFF THE SET SCREW(S) SO THEY ARE CLEAR OF THE

SET SCREWS

TOP (ROTARÝ)

HALF OF SEAL

O-RING-

**SEALING** FACES (BLUE)<sup>1</sup>

BORE.

SEPARATED (AS RECEIVED)

QUICK START GUIDE (QSG)

**SERIES: ALL** 

E-MAIL: INFO@FUSIONFLUID.COM

PHONE: 877.812.7573

WEBSITE: FUSIONFLUID.COM

## **BDRA SEAL INSTALLATION**

## **CAUTION:**

SET-UP CLIPS

SHAFT

O-RING

**BOTTOM** 

(STATIONARY)


HALF OF SEAL

- CLEAN SEAL FACES WITH AN ISOPROPYL WIPE OR CLEAN LINT FREE CLOTH
- DO NOT TOUCH SEAL FACES WITH BARE HANDS OR DIRTY GLOVED HANDS

3.) INSERT THE SHAFT THROUGH THE BOTTOM OF THE PEDESTAL AND THE BOTTOM (STATIONARY) HALF OF THE SEAL. BE CAREFUL TO AVOID HITTING THE SEAL FACE WITH THE SHAFT.

DRIVE ACCORDING TO THE APPROPRIATE SHAFT INSTALLATION QSG. ENSURE THE SEAL FACES ARE STILL CLEAN. SLIDE THE TOP (ROTARY) HALF DOWN TO THE BOTTOM (STATIONARY) HALF OF THE SEAL. ENSURE THE **ROTARY & STATIONARY SEAL FACES ARE** IN CONTACT.

5.) ATTACH THE SHAFT TO THE MIXER




4.) INSERT THE TOP (ROTARY) HALF OF THE SEAL ONTO THE SHAFT. LEAVE IT "FLOATING" ON THE SHAFT, DO NOT SLIDE IT DOWN SO THE MATING FACES ARE TOUCHING YET.

6.) THREAD IN THE SEALS SET SCREW(S) IN AN ALTERNATING PATTERN UNTIL THEY ARE BARELY TOUCHING THE SHAFT. DO NOT TIGHTEN ONE FULLY THEN THE OTHER. ONCE ALL SET SCREW(S) ARE


7.) REMOVE THE SET-UP CLIPS AND **RETAIN FOR FUTURE USE.** THEY WILL BE

SNUG, TORQUE TO THE APPROPRIATE VALUE IN THE TABLE.



OTHERWISE DAMAGE MAY OCCUR. PUSH HERE

> NEEDED IN THE FUTURE WHEN THE SEAL IS REMOVED. REMOVE SET-UP CLIPS **BEFORE OPERATING** MIXER\*





CAUTION: THE VISCOSITY AND SPECIFIC GRAVITY OF THE FLUID AFFECTS MIXER SIZING AND SPECIFICATIONS