



HUB INSTALLATION WITH CAPTURED KEY

(IF EQUIPPED)


1.) SLIDE THE IMPELLER HUB CLOSEST TO THE MIXER DRIVE ONTO THE SHAFT FIRST. SLIDE IT SO IT'S ABOVE THE SLOT FOR THE KEY, AS SHOWN. (MIXER MAY HAVE MULTIPLE IMPELLERS)



2.) INSERT THE KEY INTO THE SHAFT'S SLOT AND SLIDE THE HUB OVER THE KEY, ALIGNING THE KEYWAY IN THE HUB WITH THE KEY.



3.) TIGHTEN THE SET SCREW IN THE HUB TO THE APPROPRIATE VALUE IN THE TABLE.



4.) IF THERE ARE MULTIPLE UPPER IMPELLERS, REPEAT THIS PROCESS FOR HOWEVER MANY THERE ARE.



CAUTION:


QUICK START GUIDE (QSG)

SERIES: ALL


IMPELLER HUB WITH KEY INSTALLATION

HUB INSTALLATION WITH BOLTED KEY


1.) SLIDE THE IMPELLER HUB ONTO THE SHAFT PAST THE SLOT FOR THE KEY, AS SHOWN.



2.) INSERT THE KEY INTO THE SHAFT'S SLOT AND SECURE IT WITH THE TWO BOLTS (PROVIDED). TORQUE TO THE APPROPRIATE VALUE IN THE TABLE.



3.) SLIDE THE HUB OVER THE KEY, ALIGNING THE KEYWAY IN THE HUB




BOLT 18-8 & 304 316 SIZE **STAINLESS STAINLESS** 10-32 30 in-lb. 31 in-lb. 57 in-lb. 1/4-20 60 in-lb. 3/8-16 17 ft-lb. 16 ft-lb. 1/2-13 36 ft-lb. 38 ft-lb. 5/8-11 81 ft-lb. 84 ft-lb.


4.) TIGHTEN THE SET SCREW IN THE HUB TO THE APPROPRIATE VALUE IN

PHONE: 877.812.7573

E-MAIL: INFO@FUSIONFLUID.COM WEBSITE: FUSIONFLUID.COM



TYPICAL IMPELLER HUB CONFIGURATION SHOWN, REFER TO THE MIXER'S APPROVAL (OR AS MANUFACTURED) DRAWING FOR SPECIFICS ON YOUR MIXER'S IMPELLER CONFIGURATION.



- IMPELLER HUBS ARE SHOWN WITHOUT THE BLADES ATTACHED FOR REDUCED WEIGHT DURING INSTALLATION. IF WEIGHT IS NOT AN ISSUE, THE BLADES MAY BE ATTACHED FOR
- ONCE ALL HUB(S) ARE INSTALLED, THE BLADES CAN BE INSTALLED TO THE HUBS BY FOLLOWING THE APPROPRIATE BLADE INSTALLATION QSG.

THE VISCOSITY AND SPECIFIC GRAVITY OF THE FLUID AFFECTS MIXER SIZING AND SPECIFICATIONS