


1.) REFER TO THE QUICK START GUIDE FOR SHAFT INSTALLATION TO ATTACH THE SHAFT TO THE MIXER DRIVE.



3.) REFER TO THE QUICK START GUIDE FOR IMPELLER INSTALLATION TO ATTACH THE IMPELLER TO THE SHAFT.

5.) SWING THE TIE ROD ARMS OUT AND THREAD OTHER END OF THE TIE ROD ONTO IT. REPEAT FOR ALL TIE RODS.



2.) SLIDE THE TOTE CAP UP THE SHAFT AND THREAD THE SUPPLIED TOTE CAP ONTO THE MIXERS 2" NPT BUNG. BE



4.) CAREFULLY LIFT THE MIXER OVER THE TOTE'S HOLE, THEN LOWER THE IMPELLER AND SHAFT THROUGH THE HOLE. ONCE THE TOTE CAP MAKES CONTACT WITH THE TOTE, ROTATE THE WHOLE MIXER CLOCKWISE TO THREAD THE TOTE CAP TO THE TOTE.

6.) ATTACH HOOK TO TOTE CAGE AND TIGHTEN TIE ROD ASSEMBLY. IDEALLY ATTACH THEM WHERE THE TOP RAIL AND A VERTICAL RAILS MEET. TIGHTEN HEX NUTS TO PREVENT LOOSENING. REPEAT FOR ALL TIE RODS.

