

QUICK START GUIDE (QSG)

SERIES: ALL


SDRG SEAL INSTALLATION

CAUTION:

SEALING FACE

- **CLEAN SEAL FACES WITH AN ISOPROPYL** WIPE OR CLEAN LINT FREE CLOTH
- DO NOT TOUCH SEAL FACES WITH BARE HANDS OR DIRTY GLOVED HANDS
- **STATIONARY SEALING FACE AND O-RINGS** CAN FALL OUT OF SEAL GLAND, WHEN HANDLING, BE SURE THEY DON'T FALL

SDRG SEAL IS SHOWN SEPARATED (AS RECEIVED)




HALF OF SEAL


CROSS-SECTION OF STATIONARY

> O-RINGS


1.) APPLY PROCESS COMPATIBLE LUBRICANT TO THE SHAFT O-RING IN THE TOP HALF OF THE SEAL, BEING CAREFUL NOT TO ALLOW ANY TO MAKE CONTACT WITH THE SEALS MATING SURFACES. BACK OFF THE SET SCREW(S) SO THEY ARE CLEAR OF THE **SET SCREWS** BORE.




2.) PLACE A U-SHAPED PIECE OF CARDSTOCK (SEE BACK FOR TEMPLATE) BETWEEN THE STATIONARY HALF OF THE SEAL AND THE PEDESTAL BORE. THIS PREVENTS THE STATIONARY HALF FROM SITTING IN THE PEDESTAL BORE.



3.) INSERT THE SHAFT THROUGH THE BOTTOM OF THE PEDESTAL, THE STATIONARY HALF OF THE SEAL, AND THE ROTARY HALF OF THE SEAL.



4.) NOW THE ROTARY HALF OF THE SEAL IS "FLOATED" ON THE SHAFT, ATTACH THE SHAFT TO THE MIXER DRIVE ACCORDING TO THE APPROPRIATE SHAFT INSTALLATION QSG.



8.) REMOVE THE SET-UP CLIPS AND **RETAIN FOR FUTURE USE.** THEY WILL BE NEEDED IN THE FUTURE WHEN THE SEAL



PLACE THE STATIONARY HALF INTO THE PEDESTAL BORE, ALIGNING THE HOLES IN THE SEAL TO THE HOLES IN THE PEDESTAL. INSERT AND TIGHTEN THE 4 PROVIDED 5/16" BOLTS TO 103


5.) REMOVE THE CARDSTOCK AND


E-MAIL: INFO@FUSIONFLUID.COM WEBSITE: FUSIONFLUID.COM

PHONE: 877.812.7573



SEALING FACE.





POWER SOURCE BEFORE ASSEMBLING, LIFTING, MOVING, OR SERVICING MIXER.

CAUTION:

THE VISCOSITY AND SPECIFIC GRAVITY OF THE FLUID AFFECTS MIXER SIZING AND SPECIFICATIONS

USE THIS TEMPLATE TO CUT OUT THE U-SHAPED CARDSTOCK. DO NOT CUT THIS PIECE OF PAPER (QSG). MAY NEED TO TRIM TO FIT INTO PEDESTAL.

