

QUICK START GUIDE (QSG)

SERIES: ALL

SHAFT IDENTIFICATION

PHONE: 877.812.7573
 E-MAIL: INFO@FUSIONFLUID.COM
 WEBSITE: FUSIONFLUID.COM

LINK TO HOW TO VIDEOS



QSG-154-A

1.) IT IS IMPERATIVE THAT SHAFT AND COUPLING SERIAL NUMBERS MATCH THE SERIAL NUMBER FOUND ON THE DRIVE. THIS ENSURES THE MIXER SEES THE SAME PERFORMANCE AS DURING FACTORY TESTING.






2.) MIXER SHAFTS ARE STAMPED ON DRIVE-SIDE FACES USING THE #####-### FORMAT (EXAMPLE: 250249-101). WHEN SPACE IS RESTRICTED ON PRO SERIES SHAFTS, ONLY THE LAST THREE DIGITS MAY BE APPLIED.



3.) ON MIXERS WITH MULTIPLE SHAFT SEGMENTS, SERIAL NUMBERS WILL BE FOUND ON THE DRIVE AND EACH SHAFT SEGMENT.

4.) SHAFTS AND SHAFT CONNECTIONS MAY HAVE ALIGNMENT MARKS. REFER TO THE APPROPRIATE QUICK START GUIDE FOR YOUR TYPE OF SHAFT CONNECTION.



CAUTION

DISCONNECT MIXER FROM
 POWER SOURCE BEFORE
 ASSEMBLING, LIFTING,
 MOVING, OR SERVICING MIXER.

CAUTION:

- SUPPORT THE SHAFT TO PREVENT UNINTENDED MOVEMENT