

1.) WITH THE MIXER DISCONNECTED

FROM POWER AND BEFORE THE

**USE OF SERVICE REMOVEABLE** 

THEM TO 16 FT-LB.

QSG-105-A

## QUICK START GUIDE (QSG)

**SERIES: BULK LID** 

MOUNTING INSTRUCTIONS





HIGH SPEED **LOW TORQUE ELECTRIC DRIVE** 

DRUM LID MOUNT



DRUM LID MOUNT

**HIGH SPEED** 

**LOW TORQUE** 

AIR DRIVE



ON THE DRUM.

THE MIXER SO THE DRUM LID MOUNT

LOWER THE MIXER DOWN ONTO THE

AND THE DRUM ARE ALIGNED. CAREFULLY

DRUM UNTIL THE LID MOUNT IS RESTING

DRUM LID MOUNT

**LOW SPEED** 

**HIGH TORQUE** 

**ELECTRIC DRIVE** 



DRUM LID MOUNT

LOW SPEED

HIGH TORQUE

AIR DRIVE

3.) LIFT MIXER OVER DRUM AND POSITION


4.) INSTALL CLOSING RING AND TIGHTEN.

PHONE: 877.812.7573

E-MAIL: INFO@FUSIONFLUID.COM WEBSITE: FUSIONFLUID.COM

DO NOT LAY MIXER ON THE SHAFT

SHAFT IS INSTALLED, LIFT MIXER DRIVE ONTO THE LID DRUM. ATTACH 2.) REFER TO THE QUICK START THE DRUM LID TO THE MIXER DRIVE GUIDE FOR SHAFT INSTALLATION, USING THE 4 PROVIDED 3/8" BOLTS. THEN IMPELLER INSTALLATION TO ATTACH THE SHAFT THEN THREAD-LOCKER RECOMMENDED. IMPELLER.



LIFTING HANDLES


DISCONNECT MIXER FROM **POWER SOURCE BEFORE** ASSEMBLING, LIFTING, MOVING, OR SERVICING MIXER

DO NOT LAY/REST SHAFT ON RIM OF DRUM



**CLOSING RING** (NOT SUPPLIED BY FUSION)

**SURFACE** 



**CAUTION:** 

THE VISCOSITY AND SPECIFIC GRAVITY OF THE FLUID AFFECTS MIXER SIZING AND SPECIFICATIONS